

Choosing a hand spray pattern

Whether you're cleaning or watering, there's a hand spray for the job. By choosing the right one and using the right settings, you can save time and reduce your water bill.



The shower spray pattern gives a soft stream of water, so it's great for watering most plants without disturbing compost.



Full Spray

The full spray pattern is like the shower, but because it's more powerful it's better for watering more sturdy plants from further away. Use this spray to fill buckets quickly.



Mist Spray

If you need an even finer flow of water for seedlings and other delicate plants and flowers (or those that need humidity, like orchids), use the mist spray setting.



POPE

The jet spray setting is too strong for plants, but it has plenty of power for hosing down your driveway, pathways or pavers.





Cone Spray

To water several plants at once, choose the cone pattern. It gives a light circular spray to save time — and water even the most delicate plants without damaging the foliage.



Centre Spray

Sometimes you need a strong stream of water for a more precise soak — such as when you're washing the car. Choose the centre spray pattern for these jobs.



Flat Spray

The flat pattern has a V horizontal spray for watering a row of plants or cleaning broad surfaces likes cars, walls and windows.



Pope Tip

*

Reach new heights with the 45cm or 70cm Deluxe Wands, that make it a breeze to water taller plants, hanging baskets or reach right to the roots of your plants.

Browse the range at popeproducts.com.au

